

# **KS108 Switch User Manual**

### **Package Contents**

The following items should be found in your box:

One KS108 Switch

One Power Adapter

One Ethernet Cable

One CD

#### Note:

Make sure that the box contains the above items. If any of the listed items are damaged or missing, please contact with your distributor.

#### Content

| Chapter 1. Introduction of the Product     | 4 |
|--|---|
| 1.1 Overview of the Product                | 4 |
| 1.2 Features                               | 4 |
| Chapter 2. Installation                    | 4 |
| 2.1 Mounting the Switch on a Desk          | 4 |
| 2.2 Power On                               | 5 |
| Chapter 3. Identifying External Components | 5 |
| 3.1 Front Panel                            | 5 |
| 3.2 Rear Panel                             | 6 |
| Appendix A: Specifications                 | 7 |
| Appendix B: Troubleshooting                |   |

## **Chapter 1. Introduction of the Product**

Thank you for choosing the KS108 10/100Mbps Desktop Switch.

#### 1.1 Overview of the Product

The KS108 architecture is the optimal solution for consumer switching needs with its support for high-performance line rate capabilities and ability to identify and prioritize different data packet types within the switch while simultaneously assigning voice packets a higher priority for outbound communications. The KS108 is poised to drive the unmanaged and Smart switch, WLAN router, and CPE/Gateway markets with its comprehensive Layer 2 feature set, support for both DSL/cable modem and WLAN connectivity, and an industry-leading switching capacity—all on a single chip.

#### 1.2 Features

Complies with IEEE 802.3, IEEE 802.3u standards

8 10/100Mbps Auto-Negotiation RJ45 ports supporting Auto-MDI/MDIX

Supports IEEE802.3x flow control for Full Duplex mode and backpressure for Half Duplex mode

Supports MAC address auto-learning and auto-aging

LED indicators for monitoring power, link, activity

Plastic case, desktop or wall-mounting design

External Power Adapter supply

## **Chapter 2. Installation**

#### 2.1 Mounting the Switch on a Desk

To install the Switch, please follow the steps:

- 1) You can place the Switch on a flat desk.
- 2) Please inspect the Power Adapter carefully and make sure that it is properly connected to a power source.
- Ensure adequate ventilation space around the switch for dissipating heat and air.

Note:

Please avoid any heavy thing placed on the switch.

#### 2.2 Power On

Powering on the Switch, it will automatically initialize and its LED indicators will respond as follows:

- 1) All of the Link/Act LED indicators will flash momentarily, which represents a resetting of the system.
- 2) The Power LED indicator will light all the time.

#### Note:

If the LED indicators don't respond as described above, please check the power supply and its connection.

## **Chapter 3. Identifying External Components**

This Chapter describes the front panel, rear panel and LED indicators of the Switch.

#### 3.1 Front Panel



Figure 3-1 KS108 Switch Front Panel

The Switch's LEDs are located on the front panel.


**Power LED:** This indicator will light up when the Switch powers on.

**LEDs (1-8):** LED indicator will light green when a device is connected to the

corresponding port. It flashes when data is being transmitted or received

on the connection.

#### 3.2 Rear Panel



The following parts are located on the rear panel:

**Power:** The Power socket is where you will connect the power adapter.

Please use the power adapter provided with this KS108 Switch.

Port (1-8): The KS108 Switch is equipped with 8 10/100 Auto-Negotiation RJ45 ports where you will

connect your network devices.

The working status can be indicated by the corresponding LEDs on the front panel.

## **Appendix A: Specifications**

| Standards and Protocols | IEEE 802.3, 802.3u, 802.3ab, 802.3x CSMA/CD, TCP/IP |
|-------------------------|---|
| Basic Function          | Wire-speed Performance                              |
|                         | MAC Address Auto-learning and Auto-aging            |
|                         | IEEE 802.3x flow control for full-duplex mode and   |
|                         | backpressure for half-duplex mode                   |
| Backbound Bandwidth     | 10Gbps  |
| MAC Address Table       | 4k  |
| Forwarding Rate         | 10BASE-T: 14880pps/port                             |
|                         | 100BASE-TX: 148800pps/port                          |
| Transmission Method     | Store-and-Forward                                   |
| Ports                   | 8 10/100Mbps Auto-Negotiation RJ45 ports (Auto      |
|                         | MDI/MDIX)   |
| Network Media           | 10Base-T: UTP category 3, 4, 5 cable (maximum 100m) |
|                         | EIA/TIA-568 100Ù STP (maximum 100m)                 |
|                         | 100Base-Tx: UTP category 5, 5e cable (maximum 100m) |
|                         | EIA/TIA-568 100Ù STP (maximum 100m)                 |
| LED Indicators          | Power, 100Mbps, Link/Act                            |
| Safety and Emission     | FCC, CE   |
| Environment             | 0°C ~40°C (32°F ~104°F)                             |
|                         | -40℃ ~70℃ (-40℉ ~158℉)                              |
|                         | 10%~90% non-condensing                              |
|                         | 5%~90% non-condensing                               |
| Power                   | External Power Adapter                              |

## **Appendix B: Troubleshooting**

#### 1. The Power LED is not lit

Check to see if the power cord is connected to the Switch properly, and make sure the power source is ON.

# 2. The Link/Act LED is not lit when a device is connected to the corresponding port

Check to see if the cable connectors are firmly plugged into the Switch and the device, and verify the connected device is turned on and working well. Make sure the cable is not longer than 100 meters (328 feet)